HOW TO USE YOUR EASIWAY DIPTANK



PREP LIKE A PRO

- Remove tape and scrape off excess ink.



DIP & DWELL

- Submerge the screen in the diptank filled with an Easiway-approved ink and emulsion remover.
- Let it soak for 30 seconds to 1 minute, allowing the solution to break down ink and emulsion.



RINSE & BLAST

- Pull out the screen, tilting it to drain excess solution into the tank.
- Blast both sides (substrate side first) with a high-pressure washer to remove loosened ink and emulsion.



FINAL TOUCHES

- Spray both sides with an Easiway-approved screenwash/stain remover.
- Use small circular motions to scrub any remaining ink or stains.
- Powerwash the screen again to ensure a spotless clean.



RINSE

- Thoroughly rinse the screen.
- End with a low-pressure flood rinse until all bubbles are gone and water flows smoothly.



INSPECT & DRY

- Hold the screen up to a light source to confirm a fully cleaned surface.

HOW TO SET UP YOUR DIPTANK

DID YOU KNOW ONE PERSON CAN EASILY RECLAIM ***30 TO 50*** *SCREEN PER HOUR?*

1. Place the tank within close proximity of the washout booth or the area screens will be rinsed.

2. Fill the tank 2/3 full with water

3. Add EasiStrip SUPRA or an Easiway-approved ink and emulsion remover. Leave enough room to submerge screens.

**MIX RATIOS USING EASISTRIP SUPRA ONE STEP INK CLEANER & EMULSION REMOVER*

TANK	VOLUME	DIMENSIONS	RATIO	CHEMICAL	WATER
PT-506	14 Gallons *53 Liters*	24"W x 4.5"D x 30"H	1:7	2 Gallons	Up to 12 Gallons
PT-525	25 Gallons *95 Liters*	37"W x 13"D x 28"H	1:7	4 Gallons	Up to 21 Gallons
PT-520	37 Gallons *140 Liters*	30"W x 8"D x 36"H	1:7	5 Gallons	Up to 32 Gallons

sales@easiway.com | 763-972-6306 | www.easiway.com